

MOTOR CONTROL

REGAL

MD100G Series, Low Voltage Variable Frequency Drive

Quick Start Manual



marathon™
Drives

A Regal Brand

REGAL

www.regalaustralia.com.au

MD100G Quick Start Up Instructions

This is for use by persons familiar with vfds and is intended to highlight details specific to this model for the purpose of commissioning.

Page 1 of 2


Wiring

It is assumed personnel using this document are familiar with local code requirements for wire size & circuit protection, the dangers associated with high voltage, and are capable of safely mechanically mounting the VFD.

1 Motor FLA can never exceed VFD output rating. Check VFD nameplate to ensure compatibility. Confirm the line voltage is within the VFD input range.

2 Mounting clearances: 4" above and 2" from the sides of the enclosure. VFD must be mounted vertically to ensure adequate cooling.

For side by side installation - remove **top covers** (n/a on 4KW and below) using flat blade screwdriver.



3 Remove **front cover** (one bolt), and **control circuit cover** (both hinge at the top).

Remove **able guide** in the power section by pressing in both edges and pulling out at the same time (5.5 KW and above)

4 Identify motor connections U,V,W, and Connect motor leads at this time. **Do not connect anything to P1, P2, or N(-).**



5 Ground the inverter properly using the provided ground lugs. **Do not** daisy chain grounds. **Never power a VFD that is ungrounded.**

6 Control wiring is shown below for the most common dry contact start / analog speed reference configurations.

i/O (Blue) Terminal block functions

labels visible by the wire entrance

P1 = fwd start/run (CCW rotation shaft end)

P2 = rev start/run *motor rotation can also be reversed by switching any two motor leads*

P3 = emeg. Stop

P4 = alarm reset

Use CM terminal for P1-P7 connections.

Externally Sourced 0-10VDC or 4-20mA





12

Internally Sourced using Pot.

Maximum Voltage Output: 12V


- Maximum Current Output: 100mA
- Potentiometer: 1-5kΩ



SW 1 = **NPN/**PNP **Bold = default**
 SW2: input Volt./Curr.
 SW3 = output Volt./Curr.
 SW4 = term. res. on/off

3 wire operation (push button)

Change parameter IN.69 = 14



Terminal 'EG' is used only for open collector output (Q1)

7 With control wiring complete, connect de-energized line side power cabling to R(L1), S(L2), T(L3). These terminals are located are on the lower left side.

8 Re-install cable guide, control circuit and power covers before energizing branch circuit protection feeding the VFD.



Double check at this time to ensure the ground circuit is firmly connected to both the inverter and earth ground.



Anytime after mains power is disconnected from VFD input terminals wait 10 minutes before removing any covers.

S100 Start Up Instructions

Page 2 of 2
Parameters
Test Run

Failure to set the motor parameters correctly can cause permanent motor damage.
Confirm shaft rotation before coupling load to motor to avoid equipment damage.



<p>Motor 1</p> <p>Begin by pressing once and four times to display dr.14</p> <p>Press 'ENT'. Use and to select motor kW (kW = HP/ 1.341)</p> <p>Press 'ENT' twice and the value will be set.</p>	<p>Acc/Dec 4</p> <p>With the display not on a parameter group but instead 0.00 hit the and ACC will appear. Presses 'ENT' and enter acceleration in seconds. To repeat for dEC press again.</p> <p><i>Default values may be too long for some machines, while being too short for some fans and pumps.</i></p>	<p>Rotation check using jog 7</p> <p>Set dr.90 to '1'. Pressing 'ESC' will now enable the jog function</p> <p>Press and hold and the unit will accelerate the motor to 10 Hz.</p> <p>(accelerating to 10 Hz shown) </p> <p>Release and the unit will ramp to zero. Jog speed can be changed in : dr.11</p>	<p>Troubleshooting</p> <p>Unit does not power up</p> <p><i>Verify voltage at input terminals</i></p> <p>VFD will not rotate motor shaft even though displays shows 60Hz</p> <ul style="list-style-type: none"> - Verify motor connections U, V, W - Jumper start command (blue terminal block P1 to CM) to ensure run command received <p>Alarms</p> <p>OVT Overvoltage</p> <ul style="list-style-type: none"> - Increase deceleration time - Verify VFD grounding <p>OCT Overcurrent</p> <ul style="list-style-type: none"> - Increase acceleration time - If using PID reduce gains
<p>Next set motor data and line voltage:</p> <p>using scroll to br.0 then use to scroll to below:</p> <ul style="list-style-type: none"> poles br.11 4 = 1800 rpm nameplate rpm br.12 e.g., 1785 rated A br.13 nameplate FLA motor voltage br.15 nameplate data efficiency br.16 displayed as % line voltage br.19 e.g., 208, 480V 	<p>Loss of Speed Reference 5</p> <p>When speed signal loss is encountered default reaction is run to at 0 Hz.</p> <p>action taken Pr.12 0 = run freq. set in Pr.14</p> <ul style="list-style-type: none"> 1 = free wheel 2 = decel to stop <p>speed at loss Pr.14 default = 0</p>	<p>If motor speed is backward, change any two motor leads at the drive terminals</p> <p>Monitor Functions</p> <p>With 0.00 displayed press three times. Displayed in sequential order:</p> <ul style="list-style-type: none"> uOL Output Voltage dCL DC Link Voltage rPn Motor RPM Uc Output Current <p>Is also possible to reverse motor rotation from the keypad, using: dr.C and choosing F or r</p>	
<p>Overload setting 2</p> <p>If fan or pump load change Pr. 4 to '0' for 120% OL setting</p> <p>For 150% OL setting, leave as '1'.</p>	<p>Min/Max frequency 6</p> <p>For some fan & pumps a minimum speed above zero may be necessary.</p> <p>on/off Ad24 0/1</p> <p>min Ad25 0.5 Hz</p> <p>max Ad25 60 Hz</p> <p>Max freq. from max. analog input defined in In.1</p>		
<p>Auto Restart 3</p> <p>If fan or pump load and auto restart after a fault is desired, change Pr. 8 to a '1' to enable function.</p> <p># of restarts Pr. 9 0-10 attempts</p> <p>sec. between Pr.10 0-60 seconds</p>			

HEAD OFFICE

19 Corporate Ave / PO Box 2340
Rowville VIC 3178 AUSTRALIA

Tel: +61 (0)3 9237 4000
Fax: +61 (0)3 9237 4010

AUSTRALIA

National Sales
1300 888 853
Drives Technical Support
1800 724 149
www.regalaustralia.com.au
www.regalbeloit.com

REGAL BELOIT AUSTRALIA Pty Ltd
ABN 61 122 303 084

VICTORIA

MELBOURNE
19 Corporate Avenue
Rowville VIC 3178
Tel: +61 (0)3 9237 4040
Fax: +61 (0)3 9237 4050

NEW SOUTH WALES

SYDNEY
6-7 Bushells Place
Wetherill Park NSW 2164
Tel: +61 (0)2 8781 3100
Fax: +61 (0)2 8781 3131

TASMANIA

DEVONPORT
115 Don Road
Devonport TAS 7310
Tel: +61 (0)3 6424 8574
Fax: +61 (0)3 6424 9393

NEW ZEALAND

CMG Electric Motors (NZ) Ltd
18 Jomac Place
Avondale Auckland
NEW ZEALAND
Tel: +64 9820 3550
Fax: +64 9820 8504

SINGAPORE

CMG Electric Motors
(Asia Pacific) Pte Ltd
12 Tuas Loop 637346
SINGAPORE
Tel: +65 6863 3473
Fax: +65 6863 3476

QUEENSLAND

BRISBANE
7 Mahogany Court
Willawong QLD 4110
Tel: +61 (0)7 3246 3246
Fax: +61 (0)7 3246 3210

CAIRNS ("Service - Repairs - Sales")

2/159-161 Newell Street
Bungalow QLD 4870
Tel: +61 (0)7 4033 1109
Fax: +61 (0)7 4033 5553

MACKAY

Paget Mackay QLD 4740
Tel: +61 (0)7 4952 6244
Fax: +61 (0)7 4952 6277

THAILAND

FASCO Motors (Thailand) Limited
29/7-8 Bangkruay-Sainoi Road
Bangkrang, Muang Nonthaburi
District Nonthaburi 11000 THAILAND
Tel: +66 2447 3300
Fax: +66 2447 3500

MALAYSIA

Torin Industries SND BHD
(MALAYSIA)
No. 6536A Jalan Bukit Kemuning
Batu 6 Seksyen 34
40470 Shah Alam Selangor
Tel: +60 3 51246157
Fax: +60 3 51211467

SOUTH AUSTRALIA

ADELAIDE
47 Research Road
Pooraka SA 5095
Tel: +61 (0)8 8359 1321
Fax: +61 (0)8 8359 5675

WESTERN AUSTRALIA

PERTH
21 Colin Jamieson Drive
Welshpool WA 6106
Tel: +61 (0)8 6253 3700
Fax: +61 (0)8 6253 3710